

# easySOAP

- Ready to use solution for connection of liquid soap pumps
- 6 nipples at the back panel (not on LMA700-1800, LH1200)
- Connected to the soap hopper or liquid soap collector (not on LMA700-1800, LH1200)
- Electrical connection to the plastic box on the back side of the machine (not on LMA)
- Programmer can control up to 8 signals of the pumps



	EasySoap as standard	EasySoap optional
<b>LA 60-70</b>	-	-
<b>LAC range</b>	-	+
<b>LH range</b>	- + LH1250	+
<b>AH range</b>	-	+
<b>LN range</b>	-	+
<b>LMA range</b>	+	-